




EP G2

Installation and Technical Data



15-stage Electric Boiler
EP 150, EP 225, EP 300
and EP 350 G2 400V

Contents

1. About the Manual	4
2. General Information	4
2.1. Disclaimer	4
2.2. Legends - Warnings	5
2.3. Safety	5
2.4. Handling	6
3. Installation Information	7
4. Overview	8
5. Functions	8
5.1. Safety	8
5.2. Alarm Indication	8
5.3. Zero-voltage Switching	8
5.4. Level Sensor	8
5.5. Load Limiter	8
5.6. Pump Maintenance Operation	9
5.7. External Power Limiting	9
5.8. External Temperature Setpoint	9
5.9. Output Signal for Present Power and Temperature	9
5.10. Aluminium and Copper	9
5.11. Stainless Steel Immersion Heaters	9
5.12. Cooling Fans	9
5.13. Direct Power Control - DPC (Option)	9
5.14. Outdoor Temperature Compensation - UTK (Accessory)	9
5.15. Temperature Control in Secondary Circuit (Option)	9
5.16. Modbus (Option)	9
5.17. BACnet (Option)	10
6. Installation	10
6.1. Installation Overview	10
6.2. Water Quality	10
6.3. Flow Requirements	11
6.4. Install the Boiler	12
6.5. Pipe Installation	13
6.5.1. System Principles - Legends	14
6.5.2. System Principle - Open System	14
6.5.3. System Principle - Closed System Without Release Tank	14
6.5.4. Filling and Draining	15
6.6. Electrical Installation	16
6.6.1. Electrical Safety	16
6.6.2. Power Supply	16
6.6.3. Operating Voltage	17
6.6.4. Power Supply to External Unit	17

6.6.5. External Indication of Sum Alarm	17
6.6.6. Safety Equipment - Pressure Guards	17
6.6.7. Load Limiter Secondary Measurement	18
6.6.8. Circulation Pump	18
6.6.9. Shared Safety Equipment	19
6.6.10. Output Signal of Connected Power	19
6.6.11. Output Signal of Current Boiler Temperature	19
6.6.12. External Power Limiting	19
6.6.13. External Temperature Setpoint	19
6.6.14. Outdoor Sensor (Accessory)	20
6.6.15. Modbus (Option)	20
6.6.16. BACnet (Option)	20
7. After Installation	21
7.1. Checklist Before Start-up	21
7.2. Checklist After Start-up	21
7.3. Customer Demonstration	21
8. Operation and Maintenance	22
8.1. Safety Valve	22
8.2. Cooling Fans	22
8.3. Action in the Event of a Risk of Freezing - Frost Protection	22
8.4. Venting - Water Pressure	22
8.5. Alarm, Load Switches and Safety Guards	22
8.5.1. Check the Overheating Protection Devices	23
8.5.2. Reset Overheating Protection	23
8.5.3. Reset Load Switch	23
8.5.4. Adjust Pressure Guards (Accessory)	24
8.5.5. Reset Pressure Guards (Accessory)	24
8.5.6. Zero-voltage Protection	24
8.5.7. Level Sensor	24
9. Troubleshooting	25
9.1. Irregular Operation	25
9.2. Troubleshooting Temperature Sensors	25
10. Technical Data	26
10.1. Limitation Levels	26
10.2. Electrical Specifications	26
10.3. HVAC Specifications	27
10.4. Components	28
10.5. Component Location	30
10.6. Dimensions	31
10.7. Control Circuit	32
10.8. Power Circuit, EP 150 G2 400 V	34
10.9. Power Circuit, EP 225 G2 400 V	35
10.10. Power Circuit, EP 300 - 350 G2 400 V	36
10.11. Placement of Immersion Heaters EP 150-350 G2	37

1. About the Manual

This manual contains information about and instructions for the installation, operation, and maintenance of electric boilers in the EP G2 series.

Provide the manual to the user. The user must read the manual carefully and understand its contents.

For more information about the control system, see the EP G2 Menus and Control Systems manual.

Store the manuals in the boiler.

2. General Information

The electric boiler is CE-marked. It is classified as a unit and as pressure equipment according to Directive 2014/68/EU, Article 4(3).

Electric boiler supplied with safety equipment has been reviewed by an accredited body and has been deemed to meet the requirements contained in EN 12828.

Factory-fitted safety equipment contains the following:

- 1 or 2 safety valves, depending on opening pressure and boiler power. For more information, see Chapter Technical data - Components.
- 2 x high pressure guards
- 1 x low pressure guard
- 1 x automatic vent valve

Thanks to the factory-fitted safety equipment, the boiler can be installed without emergency protection and steam collection vessel according to EN 12828. A steam collection tank is not required, because the safety valves are fitted directly onto the boiler's safety pipe. The system does not need to be equipped with dual circulation pumps or flow guards.

If national regulations and laws exist for electric boilers, these must be met prior to commissioning.

The service life of the boiler is indefinite. Check for corrosion regularly. If corrosion occurs, the assessment must be renewed.

2.1. Disclaimer

Värmebaronen hereby disclaims all liability for any damages, including personal injury, property damage, or other adverse consequences resulting from improper handling, installation, use, or maintenance of the boiler. This disclaimer also applies to any deviations from the instructions specified in this manual.

Värmebaronen AB reserves the right to change the specification without prior notice, in accordance with its policy of continuous improvement and development. Illustrations may differ from the actual product. Värmebaronen makes reservations for any proofreading or printing errors.

2.2. Legends - Warnings



Warning! Risk of injury, death or product damage!



Warning! Risk of electrical injury and death!



Warning! Risk of product damage from static electricity!



Important information and user tips!

2.3. Safety

Before installation, operation and maintenance, carefully read the manuals and documentation for connected equipment.

Installation, operation and maintenance of the boiler may only be performed by qualified individuals. Instructions in this manual, as well as applicable standards and norms for heating systems, must be followed.

In cases where the instructions in this manual violate national regulations, the latter must be followed.

Position of boiler

- Do not place the boiler in an earthquake risk area or where abnormal vibrations may occur.
- Do not place the boiler in spaces where explosive atmospheres may occur, for example dust or flammable gases.
- Position the boiler so that only authorised individuals have access.
- The space where the boiler is located must be free from pests.
- The ambient temperature must not exceed 30°C or be lower than 10°C.
- Place the boiler indoors in a heated area with a humidity that does not normally exceed 60%.

Installation, operation, maintenance

- Never disable the safety equipment!
- Only authorised persons may perform work in the boiler.
- Always contact your installation engineer for service matters.
- You are not permitted to make modifications to or convert the boiler.
- Disconnect the boiler from the power supply and lock the switches before service or repairs.
- Never carry out maintenance work/service on hot or pressurised parts.
- Do not store flammable or corrosive products near the boiler.
- Risk of electric shock. Never leave the boiler with an open door or panel, or with plates in the boiler casing removed.
- Do not start the boiler until the water system has been filled and properly vented.
- Do not use the boiler for direct heating of drinking water.

- Do not flush the boiler with water.
- Do not drill into the boiler's cladding panels. Drill shavings can damage the boiler's electronics.
- Always specify the type and manufacturing number of the boiler when contacting Värmebaronen (see the boiler's design label).

2.4. Handling

- Check that the delivery is complete.
- Always transport and store the boiler upright in a dry location.
- Temperature during transportation and storage: -25 to +55°C.
- Use the required personal protective equipment.
- When moving the boiler, never allow people to enter risk zones and never place body parts between, e.g. the boiler and a wall when the boiler is not steady on the floor.
- If the boiler is lifted after the packaging has been removed, the wooden pallet will not follow.
- When handling the boiler, be aware of its centre of gravity:

Boiler model	The boiler's centre of gravity	Slope when the boiler tips over (degrees)	Slope when the boiler tips over (per cent)
EP 150–350 G2	Approx. 65 cm from bottom frame	> 23°C	> 43%
EP 450–700 G2	Approx. 75 cm from bottom frame	> 20°C	> 35%
EP 900–1400 G2	Approx. 80 cm from the bottom frame	> 37°	> 75%

- Use a pallet lifter to transport and position the boiler in the location where it is to stand, leaving a distance from any walls to ensure there is workspace around the boiler.
- Use suitable equipment, such as a pallet lifter, when moving the boiler. In order avoid the risk of the boiler tipping over, for example, on stairs or slopes, use a crane.
- The boiler may slide off if it is lifted “steel-on-steel” with a pallet lifter! The boiler may slide or rock if the surface is uneven, and can then exert considerable force.
- When handling the product with a crane or similar device, make sure that the lifting device and other parts are undamaged. Never stand beneath a hoisted product.
- Sort the packaging and submit it to a recycling station.
- At the end of its service life, a boiler must be recycled. Sort the boiler's insulation as insulation, the boiler tank and cladding sheets as scrap metal, and electrical parts and electronic waste as electronic waste.

3. Installation Information

Boiler	Electrical Installer	Plumbing Installer
Serial number:	Name:	Name:
Installation date:	Telephone number:	Telephone number:

Boiler Type

Model ☐ EP 150 G2 ☐ EP 225 G2 ☐ EP 300 G2 ☐ EP 350 G2
 Art.no. 5826 5830 5836 5838

Load limiter

☐ Yes ☐ No

Main fuse A Primary transformer (xxxx/5)

Settings

Installed power kW Number of stages

Setpoint source ☐ Internal ☐ P20 ☐ P21

Input type ☐ Off ☐ Voltage ☐ Current

External power limiting ☐ Off ☐ Upper limit

Signal source ☐ P20 ☐ P21 ☐ 100%

Max limitation °C Min limitation °C

UTK settings based on outdoor temperature (optional)

-30°C -15°C 0°C 15°C


-25°C -10°C 5°C 20°C

-20°C -5°C 10°C Parallel offset

Other notes

4. Overview

- 5. Stop button
- 6. Display
- 47. Pressure gauge
- 48. Design lable



5. Functions

The EP 150-350 G2 series consists of boilers with power of 150–350 kW.

The boilers adjust the temperature, with fifteen power stages that you can limit down to one power stage.

The boilers' standard control range is 20–95°C.

The boiler can be ordered with factory-fitted safety equipment. The safety equipment includes safety valves, pressure guards and an automatic vent valve, and is judged to meet the requirements in EN12828.

5.1. Safety

The boiler is equipped with 1-4 load switches with shunt release. The boiler's overheating protection, stop button or other connected safety equipment controls when the load switches are triggered.

5.2. Alarm Indication

The boiler indicates an alarm on the control panel by the screen flashing, as well as displaying information about the cause of the alarm and when the alarm occurred. Connection for external main alarm indicator exists. It is possible to send information about the cause of the alarm and the time of the alarm via e-mail (requires network connection).

5.3. Zero-voltage Switching

The boiler requires manual restart after a power failure. The "Zero Voltage Protection Tripped" alarm appears on the display, and you have to acknowledge the alarm before the boiler can start.

You can deactivate the function after evaluation by end-users and the accredited body that assesses periodic monitoring of the boiler.

For more information, see Chapter Installation in the EP G2 Menus and Control Systems manual.

5.4. Level Sensor

To protect the immersion heaters from boiling dry, the boiler is equipped with a level guard. The level guard generates a warning and stops the boiler's control if air has accumulated at the top of the boiler.

5.5. Load Limiter

To protect the main fuses against overload, the boiler is equipped with a load limiter.

- For boilers with an output of up to 63 kW, transformers for direct measurement are included.
- For boilers with an output of between 70–750 kW, secondary transformers are included.
- For boilers with an output over 750 kW, secondary transformers are available as an accessory.

5.6. Pump Maintenance Operation

The boiler is equipped with a connection for a circulation pump with a pump maintenance operation function.

5.7. External Power Limiting

The boiler is equipped with a connection for external blocking, analogue control signal 0-10 V or 4-20 mA for control of power.

5.8. External Temperature Setpoint

The boiler is equipped with a connection for external temperature setpoint in the form of a 0-10 V or 4-20 mA signal.

5.9. Output Signal for Present Power and Temperature

The boiler is equipped with a connection for 0-10 V output signals for the number of connected power stages and boiler temperature.

5.10. Aluminium and Copper

The boiler's load switches have connection terminals to which you can connect aluminium or copper cable. No need to splice from aluminium. Use stranded cable. For more information, see Chapter Technical Data - Electrical Specifications.

5.11. Stainless Steel Immersion Heaters

The immersion heaters are made of stainless steel.

5.12. Cooling Fans

The boiler is equipped with 0-3 filtered cooling fans depending on the boiler model. For more information about the maximum number of cooling fans, see Chapter Technical Data - Components.

5.13. Direct Power Control - DPC (Option)

The DPC is used in processes that require rapid regulation. A superior system is required that monitors the temperature and then controls the boiler power.

5.14. Outdoor Temperature Compensation - UTK (Accessory)

The boilers are supplied with control to maintain a constant boiler temperature. To regulate with a variable flow pipe temperature, an outdoor temperature sensor is available as an option.

5.15. Temperature Control in Secondary Circuit (Option)

When used with, for example, a heat exchanger, the temperature in the secondary circuit can control the boiler.

5.16. Modbus (Option)

The boiler is prepared for Modbus RTU (RS485) or TCP communication.

5.17. BACnet (Option)

The boiler is prepared for BACnet.

6. Installation

6.1. Installation Overview

1. Prepare accessories and installation materials that are not included in the boiler delivery.
2. Install the boiler.
3. Install the pipe system.
4. Fill with water.
5. Install the electricity.
6. Test the boiler in accordance with the Installation engineer's checklist.
7. Demonstrate the boiler to the customer.
8. Fill in the installation engineer's notes for the user.

6.2. Water Quality



If the water deviates from the recommended values, it can cause corrosion or deposits, which will shorten the service life of the boiler.



The oxygen content in the system water should be $<10 \mu\text{g/kg}$. If the oxygen content is higher, investigate the source and take action.

Perform a technical water analysis to check diluted water and system water quality. If the water's values deviate from the recommended values, adjust the values or use an alternative water source. To achieve an accurate analysis value, especially regarding oxygen concentration, perform sampling correctly and analyse the sample immediately. Consult a water chemistry laboratory before sampling.

From a corrosion perspective, the presence of oxygen that is supplied via air or oxygen-rich water is the biggest problem. Keep the amount of diluted water as low as possible, to avoid unnecessary oxygenation.

Hardness in water causes deposits on the boiler's heating elements. These deposits can lead to local overheating, which damages the elements.

High chloride content combined with deposits can lead to point and stress corrosion cracking, which destroys the elements in a short space of time.

Small systems

In small systems, you can usually use good quality tap water for filling and as diluting water, without degassing. Degassing of the water takes place in the boiler and the oxygen is diverted as air via air vent valves. The residue will react with the metal in the boiler, but will not cause significant corrosion as the amount of oxygen is small.

Large systems

For large systems, the requirements regarding water quality are higher. Degassing and consumption of residual oxygen last for longer and therefore cause more corrosion. Use degassed water or oxygen-consuming additives if necessary. For large systems, softened and desalinated water should be used.

Degassing

For effective degassing, heat the system immediately after filling. The boiler and system temperatures should be as high as possible during degassing.

Subject	Recommended value	Risk in the event of deviating value
pH value	7.5-8.5 pH	Lower values can result in corrosion damage.
Alkalinity	At least 60 mg/l	Corrosion.
Carbonic acid content	Max. 25 mg/l	Corrosion. Carbonic acid in combination with low pH and hardness values makes the water aggressive.
Sulphate content	Max. 100 mg/l	Corrosion. If the sulphate content is higher than the chloride content, copper corrosion may occur.
Chloride levels	Max. 100 mg/l	Corrosion. The aggressiveness of the chloride increases in combination with the presence of deposits.
Hard/Soft water	5-6 dH°	Hard water gives rise to deposits (boiler scale). Very soft water may cause corrosion damage.

6.3. Flow Requirements

To function optimally, the boiler must have a constant, sufficiently high flow. Dimension the flow so that it is within specified limits. The boiler's Δt must be between 5 and 25°C

Insufficient water flow may result in the following:

- The difference between the temperature setting and the actual temperature achieved in the boiler increases.
- Volatile regulation and increased wear on the boiler's contactors, which shorten the service life of the boiler.

Excessive water flow may result in the following:

- Vibrations and noise in the immersion heaters with reduced service life as a result.
- Unnecessary wear on the system's other components.

Recommended flow results in a Δt of 10°C at maximum boiler output.

From a safety point of view, the boiler is designed to withstand zero flow without damage. If forced circulation ceases, for example because of a closed valve or a pump that has been stopped, and only self-circulation occurs, the boiler remains unaffected and remains protected from damage.

For more information, see Chapter Technical Data - HVAC Specifications.

6.4. Install the Boiler



If you add glycol to the system, the glycol must contain corrosion-inhibiting additives.



From a safety perspective, the boiler is designed to cope with zero flow. As a result, you do not need to install a flow guard or double circulation pumps.



Remember not to block the boiler's cover plate when installing pipes and electricity.

The boiler should be positioned and assembled as follows:

- Install the boiler indoors where the ambient temperature does not exceed 30°C and does not drop below 10°C.
- The room should have a floor drain.
- Place the boiler indoors in a location that is dimensioned for the boiler's weight when it is filled with water.
- Place the boiler on a firm surface, preferably a concrete foundation.
- If the product is to stand on a soft surface, base plates must be placed under the boiler's adjustable foot bolts.
- Adjust the foot bolts so that the boiler is horizontal.
- Observe the electrical installation rules' requirements regarding free space in front of connection equipment, including when the boiler's open door or control panel limits the amount of space.
- Leave sufficient free space behind and to the sides of the boiler for routing cables/pipes, and accessibility during servicing/maintenance.
- Ensure there is sufficient ceiling height to allow the immersion heaters to be changed. For more information, see Chapter Technical Data - HVAC Specifications.

6.5. Pipe Installation












When installing pipes, keep the following in mind:



National regulations may require checks or the inspection of the boiler by an accredited body. If such regulations exist, they must be satisfied before commissioning. Inspections can include checking that the required safety equipment is available and that it is correctly dimensioned.

- Select the opening pressure of the safety valve according to the system component that tolerates the lowest pressure.
- Suitable safety equipment is specified in Swedish standard EN12828, which covers temperature, pressure, level, flow guards and safety valves.
- Perform the pipe installation so that forces from the pipe system are not transferred to the boiler.
- Insulate all pipe connections to the boiler so as to avoid the risk of burns.
- Any additional equipment must be installed as indicated by the manufacturer of the product.
- Perform the pipe installation so that vibrations are not transferred to the boiler.
- The boiler can cope with zero flow from a safety perspective, but the boiler should have an even and constant flow.
- Images showing examples of pipe systems are system principles. Design the pipe system in accordance with current regulations and standards.
- The boiler has built-in overheating protection and built-in over-temperature protection.
- Always install shut-off valves on the boiler's flow and return pipes.
- Install the circulation pump on the return pipe so that the circulation pump presses the flow through the boiler.
- Connect a fixed filling pipe with a filling valve if the system is only filled with water. Be sure to prevent backflow of the system water.
- For filling with water that is mixed with chemicals, such as glycol or corrosion-limiting additives, the filling valve must not be connected to the water supply network. Filling can be performed via a special filling station.
- When choosing the size of the expansion tank, bear in mind the change in the water volume during heating and cooling.
- Add oxygen-consuming agents if there is a risk that the water may become oxygenated. Oxygenation can occur in the event the system is leaking or is refilled frequently. If you do not add oxygen-consuming agents, corrosion may damage the immersion heaters.

6.5.1. System Principles - Legends

	Stop valve		Non return valve		Safety valve
	Shunt valve		Flow direction		Circulation pump
	Automatic venting		High pressure guard		Low pressure guard
	Open expansion tank		Closed expansion tank		


6.5.2. System Principle - Open System



Fit the boiler with a safety valve to avoid damage in the event of any blockage in the expansion system.

When assembling an open system, keep the following in mind:

- Connect the expansion tank to the boiler's flow pipe. The safety pipe should rise all the way to the expansion tank, without obstruction or possibility of shutdown.
- Dimension expansion tanks to accommodate changes in water volume due to heating and cooling.
- Expansion tanks with associated pipes must be installed in a way that protects against freezing.
- To avoid oxygenating the water, install the open expansion tank at least 2.5 metres above the highest point in the system. The height must be sufficient to avoid cavitation on the suction side of the circulation pump.




6.5.3. System Principle - Closed System Without Release Tank

When installing the boiler in a closed system, consider the following:


- Fit the boiler with approved safety equipment that prevents the boiler's pressure and temperature limits from being exceeded.
- Select the opening pressure of the safety valve based on the component in the system with the lowest pressure tolerance.
- Lock the valve to the expansion vessel in the open position to ensure correct function.
- Divert steam and liquid flowing out of the safety valve in accordance with the requirements of SS-EN 12828. The pipes should normally end on the outside of the building or be connected to an expansion tank.

- Dimension the safety valve's discharge pipe so that the pressure drop does not exceed 10% of the safety valve's opening pressure.
- Route the discharge pipe so that water pockets cannot form.
- To avoid freezing, the discharge pipe passing through the outer wall must have an inward fall. Drain the pipe at the discharge pipe's lowest point.

EP 150-300 G2



EP 350 G2



6.5.4. Filling and Draining



Follow local regulations for handling water that is mixed with chemicals.

Filling During Installation

Fill the boiler until the pressure, in the case of a cold boiler, is just above the minimum recommended pressure in the system. After installation, air may remain in the system for a period of time, making it necessary to perform repeated venting. Add more water if necessary.


For more information about water quality and degassing, see Chapter Installation - Water Quality.

Draining



Always cut the power to the boiler and lock all load switches before draining the water!

1. Disconnect power to the boiler.
2. Lock the load switches. See table: Overview of Load switches.
3. Drain the boiler through the drain valve.



Overview of Load switches

	EP 31-63 G2	EP 70-119 G2	EP 150-350 G2	EP 450-700 G2	EP 900-1400 G2
Load switch	B1	B1	B1	B1 and B2	B1, B2, B3 and B4

For more information, see Chapter Technical Data - Component Placement.

6.6. Electrical Installation

6.6.1. Electrical Safety



Electrical installation must be carried out in accordance with the applicable regulations, by an authorised electrical installer or by someone who is covered by the company's self-inspection programme. Dimension and route cables according to current electrical installation rules. For more information about the recommended cable, see Chapter Technical Data.



Always shut off the power before carrying out work on the boiler.

- Do not start the boiler until the heating system has been filled with water and properly vented.
- Risk of electric shock. Never leave the boiler with an open door or panel, or with plates in the boiler casing removed.
- Do not drill into the boiler's cover plates. Swarf can damage the boiler's electrical equipment. M6 bolts are available for fastening cable trays.
- To avoid disruption, do not lay light-current cables in direct connection with power cables.
- Lay cables so that it is possible to open doors and remove the roof plate for servicing.
- Dimension incoming cables in accordance with current regulations. Take into account e.g. ambient temperature, installation method and cable length. For more information about the recommended cable area, see Chapter Technical Data - Electrical Specifications.


6.6.2. Power Supply



Re-tighten power cable connections using torque tools 500 hrs after installation.

Remove the front roof plate and connect the power cables:

1. Remove the 4 screws (a) and angle the front edge of the roof plate 90° upwards.
2. Lift the roof plate straight up.
3. Slide cable flanges and gaskets onto the power cables.
4. Bind together the power cables.
5. If aluminium cable, grease the cable with neutral contact grease.
6. Connect PE 4-conductor cables to load switches and earth clamps
 - The tightening torque for load switches is 31 Nm.
 - The tightening torque for earth clamps is 40 Nm.
7. Anchor incoming cables.
8. Reinstall the roof plate.
9. Screw the cable flanges in place. Use the gaskets.




For more information, see Chapter Technical Data - Component Placement.

6.6.3. Operating Voltage

The boiler control circuit is supplied by an external power supply of 230V ~, fused with 6A.


An all-pole switch with a minimum break distance of 3 mm must be installed before the boiler.

For more information, see Chapter Technical data - Control circuit.



6.6.4. Power Supply to External Unit

Power supply to external unit. The maximum output load is 230V ~, 2A.



6.6.5. External Indication of Sum Alarm


Potential-free contact for indication of sum, alarms.

Connect the signal cables to output P9.

- Terminals 1-3, C-NC, are closed during operation.
- Terminals 1-2, C-NO, are closed during alarm.

The maximum output load is 230 V~, 2 A.

For more information, see Chapter Technical Data - Control Circuit.



Buzzer alarms are triggered when the following happens:


- External alarm
- Load-switch triggered or in Off position
- Pressure guard triggered
- Overheating protection triggered

6.6.6. Safety Equipment - Pressure Guards

If the boiler was supplied without pressure guards, the installation must be supplemented with these before commissioning.

Connect external safety equipment as shown in the image below.

For more information, see Chapter Technical Data - Control Circuit.



6.6.7. Load Limiter Secondary Measurement



Short circuit the current transformer when switching on/off, otherwise the circuit board can be damaged!




Only install the current transformers when the load limiter is in use.

Metering is done with primary/secondary current transformers. The electrical installer provides primary transformers, adapted to the specific needs of the facility (xxxx/5A). Secondary current transformers are supplied with boilers from 70 kW up to 750 kW.

Install secondary metering:

1. Connect with a high-voltage insulated cable with a minimum area of 0.75 mm².
2. Install the current transformers on the cables from the fuses, which must be protected.
3. Route the cable from the primary current transformer through the secondary current transformer once.
4. Connect to input P16, with common conductor to P16:4.

The load limiter is not phase-sensitive.



For more information, see Chapter Technical Data - Control Circuit.


For more information about the configuration of the load limiter, see Chapter Load limiter in the EP G2 Menus and Control Systems manual.

6.6.8. Circulation Pump

Potential-free closing contact for control to circulation pump. If the boiler controls the circulation pump, mark the circulation pump, indicating it is controlled by the boiler. The maximum output load is 230 V~, 2 A.

For more information, see Chapter Technical Data - Control Circuit.

For more information about the configuration of the circulation pump, see Chapter Installation - Fan and Pump in the EP G2 Menus and Control Systems manual.




6.6.9. Shared Safety Equipment



The alarm signal must use the same phase as boiler control!

If the boiler has to share safety equipment with other boilers in the system, connect alarm signal 230 V~ from existing safety equipment to terminal 1 in terminal block X01.




6.6.10. Output Signal of Connected Power

Read current power input at output P18 or P19 in the form of a 0-10 VDC signal. 0-10 V is equivalent to 0-100% of installed power.

Connect the signal cables to output P18 or P19.

For more information, see Chapter Technical Data - Control Circuit.

For more information about configuration of the output signal, see Chapter Installation - Analogue Output P18 or P19 in the EP G2 Menus and Control Systems manual.




6.6.11. Output Signal of Current Boiler Temperature

Read current boiler temperature in the form of a 0-10 V signal at output P18 or P19.

Connect the signal cables to output P18 or P19.

For more information, see Chapter Technical Data - Control Circuit.

For more information about configuration of the output signal, see Chapter Installation - Analogue output P18 or P19 in the EP G2 Menus and Control Systems manual.




6.6.12. External Power Limiting

Control the number of connected power stages through 4-20 mA or 0-10 VDC. Alternatively, block the power stages with a closing or breaking relay.

To control the number of power stages through current or voltage, connect the signal cables to input P20 or P21.

For more information, see Chapter Technical Data - Control Circuit.

For more information about the configuration of control signal, see Chapters Regulation - Control Signal and Installation - Analogue Input P20 or P21 in the EP G2 Menus and Control Systems manual.




6.6.13. External Temperature Setpoint

Controls the temperature set point through 4-20 mA or 0-10 VDC. Alternatively, the temperature setpoint can switch between the minimum and maximum limits using a closing or breaking relay.

To control the external temperature setpoint through current or voltage, connect the signal cables to input P20 or P21.

For more information, see Chapter Technical Data - Control Circuit.


For more information about the configuration of control signal, see Chapters Regulation, Setpoint Source, Installation - Analogue Input P20 or P21 in the EP G2 Menus and Control Systems manual.



6.6.14. Outdoor Sensor (Accessory)

Position the outdoor sensor:

- On an outdoor wall, about 2 metres from the ground.
- In a corner facing north or northwest, so that the outdoor sensor is not exposed to morning sun.
- So that the outdoor sensor is not affected by escaping hot air from vents, doors or windows.



Connect the outdoor sensor to the boiler using a cable with a cross section of at least 0.5 mm^2 and a maximum length of 30 metres. Connect the outdoor sensor to input P13.


For more information, see Chapter Technical Data - Control Circuit. For more information about the configuration of outdoor sensors, see Chapter Regulation - UTK in the EP G2 Menus and Control Systems manual.

6.6.15. Modbus (Option)

Connect RS 485 communication to input P22. Use contact P26 for network communication.

For more information, see Chapter Technical Data - Control Circuit.

For more information about the configuration of RTU communication, see Chapter Communication - Modbus in the EP G2 Menus and Control Systems manual.



6.6.16. BACnet (Option)

Connect network cable to contact P26. For more information, see Chapter Technical Data - Control Circuit.

7. After Installation

7.1. Checklist Before Start-up

- ☐ Has the electrical installation been adapted to the local power supply?
- ☐ Are the boiler and heating system filled with water and vented?
- ☐ Is the pressure correct?
- ☐ Are all pipe connections are leakproof?
- ☐ Is the vent valve open so that the air can escape?
- ☐ Are all necessary valves open?
- ☐ Are the power cable connections tightened to the specified torque?
- ☐ Is the flow direction for the circulation pump correct?
- ☐ Do all safety valves work?
- ☐ Is the space behind the busbar system free of tools or similar?
- ☐ Does all safety equipment work?

7.2. Checklist After Start-up

- ☐ Check that the circulation pump is properly set up and functioning correctly.
- ☐ If an outdoor sensor is installed, check that the outdoor sensor displays the correct temperature
- ☐ Fill in the installation information.
- ☐ Demonstrate the boiler for the customer, in accordance with the Customer Demonstration/Handover section.

7.3. Customer Demonstration

Once the boiler is installed, perform the following steps:

- Indicate where the manuals are stored.
- Demonstrate the boiler's parts and functions.
- Show how the user should fill the system with water via the filling valve.
- Explain display home screen.
- Show how the user increases and decreases the boiler's temperature, or the heating curve level, using the optional outdoor sensor.
- Demonstrate how to set the time and date.
- Explain alarms, warnings and limitations.
- Show how to acknowledge an alarm or warning.
- Show how to reset the overheating protection devices.
- Show how to reset the pressure guards.

8. Operation and Maintenance

8.1. Safety Valve

Operate the heating system's safety valves regularly to maintain the safety function.

8.2. Cooling Fans

Check and clean the fans' dirt filter at least once a year, or more frequently depending on the environment in which the boiler is installed. Dirty filters may lead to downtime.

8.3. Action in the Event of a Risk of Freezing - Frost Protection



If you suspect that any part of the heating system is frozen, the boiler must not be operated.
Call an installation engineer!



Adding glycol to the water affects the dimensioning of the expansion tank.

At very low temperatures, all parts of the heating system must remain in operation, otherwise there is a risk of frost wedging.

If the heating system is to be switched off for an extended period, the system should either be drained, or the system heating water mixed with up to 30 % glycol. Mixing glycol into the water reduces the heat capacity of the water, which may require an increased flow through the boiler. If glycol is added to the system water, it is important to ensure that the glycol contains corrosion-protective additives in sufficient quantities. When glycol breaks down, carbonic acid is formed as a by-product, increasing the risk of corrosion in the system.

8.4. Venting - Water Pressure



The pressure in a heating system varies with the temperature. Do not add water unnecessarily.

Regularly check that the system's water pressure is correct. For cold systems, the pressure must be just above the minimum recommended pressure in the system. Add water if necessary.

8.5. Alarm, Load Switches and Safety Guards



Always check the cause of a guard being triggered.
Remedy the cause if the guards are triggered repeatedly.

The boiler's load break switches are always triggered when a guard is triggered.

The following applies to guards:

- The display shows which limiter(s) has/have been triggered.

- The boiler emits a buzzer alarm and a red indicator flashes in the lower left part of the display.
- In a system in which the boiler shares safety equipment with other boilers in the system and this safety equipment is triggered, only the alarm signalling the triggering of the load switches is displayed. For more information about shared safety equipment, see Chapter Electrical Installation - Shared Safety Equipment.


8.5.1. Check the Overheating Protection Devices

To check the overheating protection devices:

1. Stop the flow through the boiler.
2. Adjust the cut-off temperature to 80°C on the back of overheating protection devices 8 and 9. See figure.
3. Adjust the boiler temperature setpoint to 90°C.

When the boiler temperature reaches the cut-off temperature, the overheating protection devices should be triggered together with the load switch.

4. Once the inspection is finished, re-adjust the cut-off temperature to 105°C.




8.5.2. Reset Overheating Protection

If the temperature exceeds 105°C, the overheating protection is triggered and stops the boiler.

To reset the overheating protection devices:

1. Check that the boiler temperature is below 80°C.
2. Press the buttons on the overheating protection devices.

See numbers 8 and 9 in the image.




8.5.3. Reset Load Switch

The load switches are set to tripped when a safety guard is triggered or when you press the STOP button on the boiler's panel.

To reset a load switch:

1. Press the "PAUSE" button next to the "Load-switch off" alarm, which appears on the boiler display.
2. Reset the load switch by turning the knob to "OFF" and then to "ON".




8.5.4. Adjust Pressure Guards (Accessory)

High Pressure Guard

Set the high pressure guard so that the trigger pressure is between the boiler's normal operating pressure and the safety valves' opening pressure.


Low Pressure Guard

Set the low pressure guard so that the trigger pressure is slightly below the system pressure when the system is not heated up.



8.5.5. Reset Pressure Guards (Accessory)

Using a screwdriver or a narrow object, reset the pressure guard by lifting the pin.



8.5.6. Zero-voltage Protection

The boiler does not restart automatically after a power cut. Manual acknowledgement is required.

It is possible to activate automatic restart, but if there are national regulations relating to restarting, perform an evaluation before activation.

For more information, see Chapter Installation in the EP G2 Menus and Control Systems manual.

8.5.7. Level Sensor

The level guard generates a warning and stops the boiler's control if air has accumulated at the top of the boiler. No acknowledgement is required, but the warning remains on the display until the fault has been remedied.

9. Troubleshooting

9.1. Irregular Operation

If the electric boiler steps up a number of stages and immediately steps down again, the reason may be that the boiler has too low a flow.

Troubleshoot the boiler by following these steps:

1. Check that circulation pumps are working.
2. Check that valves are working.
3. If no error has been detected, check that the water flow is within the desired range.

To get an estimate of the flow:

4. Limit the power stages of the boiler so that the power is constant.
5. Allow the boiler's temperature to stabilise.
6. Measure the temperature increase between the flow and return pipes of the boiler.
7. Calculate the flow through the boiler using the following formula: $q = P / (\Delta t \times 1.16)$
8. Check against the details in the chapter Technical Data, to determine whether the flow is adequate.

Formula Description

Value	Explanation
q	Water flow in m ³ /h (m ³ /h x 1000/3600 = litres/second)
P	The electric boiler's power output in kW
Δt	Temperature difference (°C) between the boiler's flow and return pipes
1.16	The water's thermal absorption coefficient

9.2. Troubleshooting Temperature Sensors

The boiler temperature sensor must not be connected to the circuit board during resistance measurement. When the boiler is energised, measure the voltage in the sensor's connection points on the circuit board.

Applies to P10, P11 and P12

°C	kΩ	Vdc
5	141,9	3,10
10	111,6	3,03
15	88,3	2,00
20	70,3	2,90
25	56,3	2,83
30	45,4	2,70
35	36,8	2,57
40	30,0	2,50

°C	kΩ	V
45	24,6	2,37
50	20,2	2,17
55	16,7	2,04
60	13,9	1,91
65	11,6	1,78
70	9,7	1,65
75	8,2	1,52
80	6,9	1,32

°C	kΩ	Vdc
85	5,9	1,25
90	5,0	1,12
95	4,3	0,99
100	3,7	0,86
105	3,2	0,79
110	2,7	0,66

Outdoor temperature sensor (for UTK), P14

°C	kΩ	Vdc
-30	47,0	2,84
-25	34,7	2,70
-20	25,9	2,57
-15	19,5	2,38
-10	14,8	2,18
-5	11,4	1,98
0	8,8	1,78

°C	kΩ	Vdc
5	6,8	1,58
10	5,4	1,39
15	4,2	1,19
20	3,4	1,06
25	2,7	0,86
30	2,2	0,73

10. Technical Data


10.1. Limitation Levels

Stage	EP 150 G2		EP 225 G2		EP 300 G2		EP 350 G2	
	kW	A	kW	A	kW	A	kW	A
1	10	14	15	22	20	29	23,3	34
2	20	29	30	43	40	58	46,6	67
3	30	43	45	65	60	87	69,9	101
4	40	58	60	87	80	116	93,2	135
5	50	72	75	108	100	144	116,5	168
6	60	87	90	130	120	173	139,8	202
7	70	101	105	152	140	202	163,1	236
8	80	115	120	173	160	231	186,4	269
9	90	130	135	195	180	260	209,7	303
10	100	144	150	216	200	289	233,0	337
11	110	159	165	238	220	318	256,3	370
12	120	173	180	260	240	346	279,6	404
13	130	188	195	281	260	375	302,9	438
14	140	202	210	303	280	404	326,2	472
15	150	216	225	325	300	433	349,5	505

10.2. Electrical Specifications

Model	EP 150 G2	EP 225 G2	EP 300 G2	EP 350 G2	
Art.no	5826	5830	5836	5838	
Voltage, power	400 V3~	400 V3~	400 V3~	400 V3~	
Voltage, power control	230 V~	230 V~	230 V~	230 V~	
Voltage tolerance	≤ ± 10%	≤ ± 10%	≤ ± 10%	≤ ± 10%	
Frequency	50 Hz	50 Hz	50 Hz	50 Hz	
Enclosure class	IP x 1	IP x 1	IP x 1	IP x 1	
Power supply system	TN	TN	TN	TN	
Short-circuit resistance	10 kA	10 kA	10 kA	10 kA	
Power	150	225	300	350	kW
Current	217	325	433	505	A
Fuse protection power, max	250	400	630	630	A
Fuse protection power, rec.	250	400 / 2x 200	500 / 2x 250	630 / 2x 315	A
Fuse protection, control	6	6	6	6	A
Number of stages	15, can be limited down to 1 stage				
Power, stage size	10	17	20	23,3	kW
Current, stage size	14,4	24,5	28,9	33,7	A
Cable flange	FL 21, Ø 60	2 x FL 33,2 x Ø 60 mm			
Wired area	120 - 240 Al/Cu	2 x 70 - 240 Al/Cu			mm²
	Connect up to 240 mm² round-pressed stranded cable.				
Rec. cable area Al	≥AXQJ 1x 185	≥AXQJ 2x 150	≥AXQJ 2x 240	≥AXQJ 2x 240	mm²
Rec. cable area Cu	≥FXQJ 1x 150	≥FXQJ 2x 120	≥FXQJ 2x 185	≥FXQJ 2x1 85	mm²

10.3. HVAC Specifications

Model	EP 150 G2	EP 225 G2	EP 300 G2	EP 350 G2	
Art. no.	5826	5830	5836	5838	
Volume	180	180	180	180	Litres
Design pressure	0,6	0,6	0,6	0,6	MPa
Design pressure	6	6	6	6	Bar
Test pressure	0,86	0,86	0,86	0,86	MPa
Test pressure	8,6	8,6	8,6	8,6	Bar
Design temperature	110	110	110	110	°C
Operating temperature	20-95	20-95	20-95	20-95	°C
Ambient temperature	≤ 10 - 30	≤ 10 - 30	≤ 10 - 30	≤ 10 - 30	°C
Connection, flow/return	DN 100PN 16	DN 100PN 16	DN 100PN 16	DN 100PN 16	
Safety pipe	2 x R32 utv	2 x R32 utv	2 x R32 utv	2 x R32 utv	
Flow requirement, recommended $\Delta t=10^{\circ}\text{C}$	3,6	5,0	7,0	8,4	Litres/ sec
Flow requirements, min/max	1,5/15	2,1/15	2,8/15	4/15	Litres/ sec
Weight (empty)	230	260	275	275	kg
Weight (filled with water)	410	440	455	455	kg
Pressure drop					
Ceiling height for immersion heater replacement	>2375	>2375	>2375	>2375	mm
Manufactured to	PED 2014/68/EU article 4.3				
EMC environment	Immunity and emission for industrial environments				

10.4. Components

Art. no.	Description	EP 150 G2	EP 225 G2	EP 300 G2	EP 350 G2
110033	Immersion heater, 10 kW	1	--	--	--
110035	Immersion heater, 15 kW	--	3	--	--
110038	Immersion heater, 20 kW	7	9	15	--
110039	Immersion heater, 23,3 kW	--	--	--	15
170080	Contactora AF 116	K4	--	K3 - K5	K3 - K5
170085	Contactora AF 26	K1, K2	K1	K1	K1
170087	Contactora AF 40	--	K2	--	--
170088	Contactora AF 52	K3	--	K2	K2
170089	Contactora AF 65	--	K3 - K5	--	--
180060	Blade fuse 35 A	--	F1	--	--
180061	Blade fuse 50 A	F1	--	F1	F1
180063	Blade fuse 80 A	F2	F2	F2	--
180064	Blade fuse 100 A	--	--	--	F2
180065	Blade fuse 125 A	--	F3 - F5	--	--
180066	Blade fuse 160 A	F3	--	F3 - F5	F3 - F5
130066	Load switch ABB XT 3 250 A	1	--	--	--
130075	Load switch XT 5 400 A	--	1	--	--
130076	Load switch XT 5 630 A	--	--	1	1
210074	Display EP G2 with contact board	1	1	1	1
210250	Circuit board, power	1	1	1	1
201252	Current measurement board	--	1	1	1
210252-V6	Current measurement board	1	--	--	--
218005	Switched power supply, 110W	1	1	1	1
700564	Temperature sensor, boiler temperature	1	1	1	1
210206	Temperature sensor, ambient temperature	1	1	1	1
360020	Current transformer, load limiter (secondary transformers)	3	3	3	3
120022	Overheating protection	2	2	2	2
130034	Pressure switch "STOP"	1	1	1	1
240350	Drain valve	1	1	1	1
380023	Manometer	1	1	1	1
380002	Check valve for 380023	1	1	1	1
300016	O-ring for check valve	1	1	1	1
300017	O-ring, 1 for each immersion heater/blind plug	1	1	1	1
500030	Filter fan	--	--	--	1

Complementary Accessories

Art.no.	Description	EP 150 G2	EP 225 G2	EP 300 G2	EP 350 G2
1921	Outdoor sensor (for UTK)	1	1	1	1
4764	Expansion board EP-VP G2 (EP 150-1400 G2)	1	1	1	1
500030	Extra filter fan	1 (max. 2)	1 (max. 2)	1 (max. 2)	1 (max. 1)
500031	Replacement filter for 500030	1	1	1	1


Safety Equipment (Accessory)

Opening pressure (bar)	EP 150 G2	EP 225 G2	EP 300 G2	EP 350 G2
1,5	4843	4843	4884	4885
2,5	4846	4847	4847	4886
3,0	4850	4851	4851	4859
4,0	4854	4854	4855	4888
6,0	4858	4858	4858	4893

Included in the Safety Equipment


Art.no.	Description	EP 150 - 300 G2	EP 350 G2
440196	Pressostat, DSH 0-6 bar	1	2
440197	Pressostat, DSL 0-6 bar	--	1
245078	Check valve for automatic air bleed valve	1	1
245076	Automatic air bleed valve	1	1
	Safety valve	1	2

10.5. Component Location




- 1. Terminal block, X01, control circuit
- 8. Overheating protection 1, STB
- 9. Overheating protection 2, STB
- 10. Switched power supply 230Vac/24Vdc
- 11. Circuit board, power
- 16. Cooling fan (option)
- 31. Current measurement circuit board
- 32. Connection, PE-conductor
- 40. Safety pipes
- 41. Automatic air vent valve
- 42. Safety valve
- 43. High pressure guard 1
- 44. High pressure guard 2
- 45. Low pressure guard
- 46. Terminal block X02, for pressure guards
- 49. Connection potential equalisation

EP 150 - 300 G2




EP 350 G2



- F1. Fuse for Power Group 1
- F2. Fuse for Power Group 2
- F3. Fuses for Power Group 3
- F4-F5. Fuses for Power Group 4
- F6-F9. Fuses for Power Group 5
- K1. Contactor, Power Group 1
- K2. Contactor, Power Group 2
- K3. Contactors, Power Group 3
- K4-K5. Contactors, Power Group 4
- B1. Load switch with auxiliary contact

10.6. Dimensions



- 33. Cable gland
- 34. Safety pipes
- 35. Flow pipe
- 36. Return pipe
- 37. Drain valve

- 38. Adjustable foot bolts
- 39. Cable flanges
- 47. Manometer
- 48. Design label

10.7. Control Circuit



Perform interventions that requires tools in the boiler's electrical equipment under the supervision of a qualified electrician!



The control voltage is not cut by the load switches! External voltage may occur!


To cut the power supply to the boiler, set the load switches in the 0 position. Lock the load switches!





Pressure guards are included in factory-fitted safety equipment (accessory).

- | | |
|---|---|
| 1. Terminal block, X01, control circuit | 19. Environmental temperature sensor, P11 |
| 2. Connector, clamps 3, 4, 5 and 6.
Remove when connecting pressure guards or safety equipment | 20. Temperature sensor, P12 (Optional) |
| 3. Connection, control voltage, 230V ~, to the boiler | 21. Connection outdoor temperature sensor, boiler with UTK, (Optional) P13. |
| 4. "STOP" button cuts the power supply to the boiler by tripping the load switch | 22. Connection for PT100 sensors, P14 and P15 (Accessory) |
| 5. Touch display | 23. Connection for the load limiter's current transformers P16. |
| 6. Display cable. Connects power and display circuit boards. | 24. Connection, level sensor, P17 |
| 7. Overheating protection 1 (STB) | 25. Analogue output, P18 and P19 |
| 8. Overheating protection 2 (STB) | 26. Analogue input, P20 and P21 |
| 9. Switched power supply, 230V AC/24V DC for supply to circuit boards | 27. Output for display, P25 |
| 10. Circuit board, power. | 28. USB 1 and USB 2 |
| 11. Connection for current measurement board, P2 (Com 1) and P3 (Com 2) | 29. Network cable connection, P26 |
| 12. Safety inputs, P4 and P5 | B1. Load switch with auxiliary contact, |
| 13. Indicator, safety inputs. Indicator lights up when: | K1. Contactor, power group 1 |
| 1. Reserved | K2. Contactor, power group 2 |
| 2. Overheating protection is in operating mode | K3. Contactors, power group 3 |
| 3. High pressure guards are in operating mode | K4, K5. Contactors, power group 4 |
| 4. Load switch is in operating mode | X03. Terminal block, fan |
| 5. Low pressure guard in operating mode. | X04. Terminal block, load switch B1 |
| 6. Reserved | Included in factory-installed safety equipment (accessory) |
| 14. Potential-free relay output for circulation pump. Max. load 230 V~/2A P7. | 43. High pressure guard 1, (Pz+) |
| 15. Cooling fan(s) P8 | 44. High pressure guard 2, (Pz+) |
| 16. Potential-free relay output for buzzer alarm P9 | 45. Low pressure guard 1, (Pz-) |
| 17. Boiler temperature sensor, P10 | 46. Terminal block, X02. Internal connection for safety equipment. |
| 18. Potential-free relay output for circulation pump. Max. load 230 V~/2A P7. | |

EP 350 G2




EP 150 - 300 G2



10.8. Power Circuit, EP 150 G2 400 V



The control voltage is not cut by the load switches! External voltage may occur! To cut the power supply to the boiler, set the load switches in the 0 position. Lock the load switches!



EP 150 G2


Power group	1	2	3	4
Power	10 kW	20 kW	40 kW	80 kW
Load switch	B1	B1	B1	B1
Fuse 3 x 50 A	F1	F1	--	--
Fuse 3 x 80 A	--	--	F2	--
Fuse 3 x 160 A	--	--	--	F4
Contactor	K1	K2	K3	K4
Immersion heater, 10 kW	1	--	--	--
Immersion heater, 20 kW	--	3	4, 5	8, 9, 10, 14

10.9. Power Circuit, EP 225 G2 400 V



The control voltage is not cut by the load switches! External voltage may occur!

To cut the power supply to the boiler, set the load switches in the 0 position. Lock the load switches!



EP 225 G2


Effektgrupp	1	2	3	4
Power	15 kW	30 kW	60 kW	120 kW
Load switch	B1	B1	B1	B1
Fuse 3 x 35 A	F1		--	--
Fuse 3 x 80 A	--	F2	--	--
Fuse 3 x 125 A	--	--	F3	F4, F5
Contactor	K1	K2	K3	K4, K5
Immersion heater, 15 kW	1	3, 4	--	--
Immersion heater, 20 kW	--	--	5, 9, 10	7, 8, 12 13, 14, 15

10.10. Power Circuit, EP 300 - 350 G2 400 V



The control voltage is not cut by the load switches! External voltage may occur!

To cut the power supply to the boiler, set the load switches in the 0 position. Lock the load switches!



EP 300 G2

Power group	1	2	3	4
Power	20 kW	40 kW	80 kW	160 kW
Load switch	B1	B1	B1	B1
Fuse 3 x 50 A	F1		--	--
Fuse 3 x 80 A	--	F2	--	--
Fuse 3 x 160 A	--	--	F3	F4, F5
Contactor	K1	K2	K3	K4, K5
Immersion heater, 20 kW	1	2, 3	4, 5, 6, 7	8, 9, 11, 12 10, 13, 14, 15


EP 350 G2

Power group	1	2	3	4
Power	23,3 kW	46,6 kW	93,2 kW	186,4 kW
Load switch	B1	B1	B1	B1
Fuse 3 x 50 A	F1		--	--
Fuse 3 x 100A	--	F2	--	--
Fuse 3 x 160A	--	--	F3	F4, F5
Contactor	K1	K2	K3	K4, K5
Immersion heater, 23,3 kW	1	2, 3	4, 5, 6, 7	8, 9, 11, 12 10, 13, 14, 15

10.11. Placement of Immersion Heaters EP 150-350 G2

The numbers indicate the location of the immersion heaters as seen from the top of the boiler tank.

- A: Temperature sensor
- B: Overheating protection.
- C: Manometer connection
- D: Level sensor





Värmebaronen AB
Arkelstorpsvägen 88
SE-291 94 Kristianstad
Tel +46 44 22 63 20
www.varmebaronen.se
www.varmebaronen.com
info@varmebaronen.se